

playmobil®

Family Fun



70439

1



**WARNING:**  
CHOKING HAZARD

Small parts. Not for children under 3 years.


"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
¡Por favor, guarde estas instrucciones para el futuro!  
Belangrijke documenten, bewaar deze zorgvuldig!

Abbildungen können vom Original abweichen.  
Product may differ from image shown.  
Les illustrations peuvent différer de l'original.  
Las ilustraciones pueden diferir del original.  
Afbeeldingen kunnen verschillen van het werkelijke artikel.



30 61 1282



30 07 2223

30 07 2233


2



30 82 9815

2

3



3




4



30 73 3882


CLICK




5



30 62 0785






1 30 07 2243



30 80 9243


30 64 4603



30 25 2633


30 25 2643

30 67 4752



2

30 23 7760




1

30 60 2422



30 23 7930

30 23 7920



30 10 4720

30 61 7940



30 14 3582

Serviceadressen finden Sie in allen PLAYMOBIL-Prospekten

Addresses of Customer Service Departments are shown in all PLAYMOBIL catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues PLAYMOBIL

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-bēēl

ASSEMBLY INSTRUCTION





70436



70438



70437

# Family Fun



70434



70435



70440



70439

